
LED FLARES <u>LANDING KIT</u> 6-PACK WITH RECHARGEABLE CASE





Four lights are placed to outline the landing zone and the fifth indicates wind direction.



FEATURES

- Choose from 9 flashing patterns
- Runs up to 100 hours
- 360 degrees of LED light
- · Shock, vibration and water-proof
- Visible for up to 10 miles
- Complies with U.S. DOT
- Rechargeable
- Powerful magnet for attaching to metal
- Safe to use in many HAZMAT situations

FLASH PATTERN – CONTINUOUS RUN TIMES

Rotate: 15 hours

Quad-Blink: 15 HoursSlow-Blink: 100 Hours

Alternate: 10 Hours

SOS: 24 Hours

Solid-On Low: 60 HoursSolid-On High: 8 Hours

Flashlight (2 LED): 30 Hours
Flashlight (4 LED): 15 Hours

FLARE OPERATING

To turn on the flare press the ON / OFF / MODE button on the upper side of the flare. The 9 different modes can be selected by repeatedly pressing the ON / OFF / MODE button. Press the button for approx. 2 seconds to turn off the flare at any mode.

RECHARGING IN THE CASE

The carrying case is also a recharging port. Be sure the flare is properly seated in the charging stall. The loop should be on top and the ON / OFF / MODE button faces up. Each charging station has an LED indicator noting if the unit is at full charge; red when charging, green when complete. The outside of the case has a master charging indicator. This will be green when all units are fully charged. If one unit is still charging, it will remain red.